

Opening Flex Micro chassis for service



Ensure Cable Shroud is disconnected and push Tab **UP** and slide chassis lid forward



Push UP and slide forwards

Opening Flex Micro chassis for service



When lid moves slightly forwards, lift from the back and tip the lid up



The lid will now come away from the main part of the chassis